


Dirtkiller



Spare parts list KRÄNZLE 160 TST, 195 TST Dirtkiller with lance

No	Description	Qty.	Ord.-No
1	Sprühkörper	1	41.520
2	O-Ring 6,88 x 1,68	1	41.521
3	Düsenstanz	1	41.522
4	Düse 045	1	41.523
4.1	Düse 03	1	41.523 4
5	Stabilisator	1	41.524
6	O-Ring	1	40.016 1
7	Sprühstopfen	1	41.526
8	Rohr 400 mm 2x M 12 x 1	1	41.527
9	ST 30-Nippel M 22 x 1,5 / M 12 x 1 ISK	1	13.363
Rep.-kit Dirtkiller 045 consisting of: 1x 2; 3; 4; 5			41.097
Rep.-kit Dirtkiller 03 consisting of: 1x 2; 3; 4.1; 5			41.096 1
Dirtkiller 045 compl. with lance			41.072 5
Dirtkiller 03 compl. with lance			41.073 8